


Figure 1

1/9
AUS9-2000-0640-US1






Figure 2




Figure 3

3/9
AUS9-2000-0640-US1

Figure 4

4/9
AUS9-2000-0640-US1





Figure 5

5/9
AUS9-2000-0640-US1



512

Figure 6

6/9
AUS9-2000-0640-US1




Figure 7

7/9
AUS9-2000-0640-US1


700

Protection Table Entry

Virtual Address of Start of Memory Region <u>702</u>
Length of Memory Region <u>704</u>
Protection Domain <u>706</u>
Local and Remote Access Control <u>708</u>
Key_Instance <u>710</u>
Address Translation Pointer <u>712</u>

Figure 8

8/9
AUS9-2000-0640-US1



9/9
AUS9-2000-0640-US1

9/9

AUS9-2000-0640-US1

